MARTHA STEWART™ LIVING

Christmas Tree
Model:WAE61011100CSE1
Sku # 1000 006 159

Safety Information

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed, including the following:

a. **READ AND FOLLOW ALL SAFETY INSTRUCTIONS.**

b. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.

c. This seasonal product is not intended for permanent installation or use.

d. Do not mount or place the product near gas or electric heaters, fireplaces, candles, or other similar sources of heat.

e. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.

f. Do not let lamps rest on the supply cord or on any wire.

g. Unplug the product when leaving the house, when retiring for the night, or if left unattended.

h. This is an electric product and not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.

i. Do not use this product for other than its intended use.

j. Do not hang ornaments or other objects from cord, wire, or light string.

k. Do not close doors or windows on the product or extensions cords as this may damage the wire insulation.

l. Do not cover the product with cloth, paper, or any material that is not a part of the product when in use.

m. This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless plug can be fully inserted. Do not alter or replace the plug.

n. This product is equipped with push-in type lamps. Do not twist lamps.

o. This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product.

p .Read and follow all instructions that are on the product or provide with the product.

q. **SAVE THESE INSTRUC TIONS**

Pre-Assembly

Package Contents

Part	Description	Quantity
A	Tree top, tag 4	1
B	Tree center 1, tag 3	1
C	Tree center 2, tag 2	1
D	Tree bottom, tag 1	1
E	Tree stand	1

Assembly

Assembling the tree stand

Step 1. Choose a location near a wall outlet.
Step 2. Unfold the legs of the tree stand (D) and lay the stand on the floor.
Step 3. Slide the locking disk of the tree stand (D) down until it snaps into place.



Assembling the tree

This tree assmebles with Quick Set® technology ---Set up and light up your tree in less than 10 minutes!

Step 1. Remove the protective caps from the tree bottom (D) and insert the pole into the tree stand (E).
Step 2. Remove the protective caps from the tree center 2 (C) and insert the pole into the tree bottom (D).
Step 3. Remove the protective caps from the tree center 1 (B) and insert the pole into the tree center 2 (C).
Step 4. Insert the tree top (A) into the tree center 1 (B).
Step 5. Shape the branches to your preference by working from the bottom to the top. When adjusting branches, ensure that all wires are free of branch hinges.
Step 6. Insert the green label extension cord plug into the wall outlet. All your lights should now be lit.
Step 7. When finished shaping the branches, slightly upsweep all branch tips for a uniform look.